Electronic Assembly Equipment

Flux Flow Monitor

Provides excellent means of verifying repeatability and alarm monitoring capability




As Industry 4.0 continues to proliferate into PCB manufacturing, process control and data management within the fluxing process becomes increasingly critical.

Electrovert's flux flow monitor is intended for applications that flux flow verification is critical to the wave soldering process. The feature provides an accurate method of verifying repeatability of the flux flow rate and flux volume on a board-to-board basis.

The flux flow monitor uses an innovative non-contact type sensor. This approach allows the feature to be compatible across a broad range of flux types and spray technologies.

Flux Flow Monitor Features:

- Compatible with a broad range of flux types:
 - Alcohol and water based
 - Low to high solid content
 - Mild to highly corrosive
- Available on Electra, VectraElite, and VectraES (single and dual-head type fluxers)
 - ServoJet
 - ServoSpray
 - ServoSonic
- Feature is field upgradable (check with the factory on vintage and configuration of machine)









Flux Flow Monitor

Flux Flow Monitor Features:

- Easily configurable in machine software
- All critical flux monitoring parameters are integrated into machine software, are recipe dependent and captures data for MES data management purposes
- User defined alarm capabilities integrated into machine software:
 - Flow rates out of tolerance
 - Flow volumes out of tolerance
 - · Restricted and leak detection alarms
- Each unit is programmed at the factory to allow an easy field upgrade installation

PROCESS & APPLICATION	SPECIFICATIONS
Flux Type Compatibility	Alcohol and water based Low to high solid content Mild to highly corrosive
Fluxer model offering	ServoSpray (single and dual-head fluxers) ServoJet (OA and non-OA) (single and dual-head fluxers) ServoSonic
Accuracy	+/- 1%
Controls	Integrated into machine software
Software	Compatible with Windows 7 and 10
Alarm settings	Percentage based and user defined
Origin	Camdenton, Missouri USA



The flux flow monitor sends alarms if flow rate is out of tolerance, flux line leak is detected, flux volume is out of tolerance, or fluxer flow is restricted.

Board not seen by Exit Sensor Chip Speed Out of Tolerance Warning Contact Length Position Stall Alarm Conveyor Speed Feedback Alarm Conveyor Speed Feedback Alarm Conveyor Speed Out of Tolerance External Flux Tank A Level Low External Flux Tank B Level Low External Fluxer Communication Fault External Fluxer Flow Rate out of Tolerance External Fluxer Flux Line Leak Detected External Fluxer Flux Volume out of Tolerance External Fluxer Restricted Flow Detected External Fluxer Solvent Level Low External Fluxer Solvent Purge Required External Fluxer North Purge Required Warning External Fluxer North Purge Required External Fluxer North Purge Required	rpm	
Contact Length Position Stall Alarm Conveyor Speed Feedback Alarm Conveyor Speed Out of Tolerance External Flux Tank A Level Low External Flux Tank B Level Low External Fluxer Communication Fault External Fluxer Flow Rate out of Tolerance External Fluxer Flux Line Leak Detected External Fluxer Flux Line Leak Detected External Fluxer Flux Communication Fault External Fluxer Flux Line Leak Detected External Fluxer Flux Communication External Fluxer Flux Line Leak Detected External Fluxer Flux Volume out of Tolerance External Fluxer Servo Controller COMM Fault External Fluxer Solvent Level Low External Fluxer Solvent Level Low External Fluxer Solvent Purge Required Warning	rpm	
Conveyor Speed Feedback Alarm Conveyor Speed Out of Tolerance External Flux Tank A Level Low External Flux Tank B Level Low External Flux Communication Fault External Fluxer Flow Rate out of Tolerance External Fluxer Flux Line Leak Detected External Fluxer Flux Line Leak Detected External Fluxer Flux Line Leak Detected External Fluxer Flux Volume out of Tolerance External Fluxer Flux Volume Flux Volume Out of Tolerance External Fluxer Servo Controller COMM Fault External Fluxer Solvent Level Low External Fluxer Solvent Level Low External Fluxer Solvent Level Low External Fluxer Solvent Purge Required Warning		
Conveyor Speed Out of Tolerance Warning 1.00 0.50 External Flux Tank A Level Low Ignore		
External Flux Tank A Level Low Ignore External Flux Tank B Level Low Ignore External Fluxer Communication Fault Warning External Fluxer Flow Rate out of Tolerance Warning External Fluxer Flux Line Leak Detected Soft-Stop External Fluxer Flux Volume out of Tolerance Warning External Fluxer Restricted Flow Detected Warning External Fluxer Servo Controller COMM Fault Warning External Fluxer Solvent Level Low Ignore External Fluxer Solvent Purge Required Warning External Fluxer Solvent Purge Required Warning External Fluxer Solvent Purge Required External Fluxer Solvent Purge Required External Fluxer Solvent Purge Required		
External Flux Tank B Level Low Ignore External Fluxer Communication Fault Warning External Fluxer Flow Rate out of Tolerance Warning External Fluxer Flux Line Leak Detected Soft-Stop External Fluxer Flux Volume out of Tolerance Warning External Fluxer Restricted Flow Detected Warning External Fluxer Servo Controller COMM Fault Warning External Fluxer Solvent Level Low Ignore External Fluxer Solvent Purge Required Warning External Fluxer Solvent Purge Required	feet/min.	
External Fluxer Communication Fault External Fluxer Flow Rate out of Tolerance External Fluxer Flux Line Leak Detected External Fluxer Flux Volume out of Tolerance External Fluxer Flux Volume out of Tolerance External Fluxer Restricted Flow Detected External Fluxer Servo Controller COMM Fault External Fluxer Solvent Level Low External Fluxer Solvent Purge Required Warning		
External Fluxer Flow Rate out of Tolerance Warning 20 10 External Fluxer Flux Line Leak Detected Soft-Stop 2 External Fluxer Flux Volume out of Tolerance Warning 20 10 External Fluxer Restricted Flow Detected Warning 2 External Fluxer Servo Controller COMM Fault Warning 2 External Fluxer Solvent Level Low Ignore 2 External Fluxer Solvent Purge Required Warning 2		
External Fluxer Flux Line Leak Detected External Fluxer Flux Volume out of Tolerance External Fluxer Restricted Flow Detected External Fluxer Servo Controller COMM Fault External Fluxer Solvent Level Low External Fluxer Solvent Purge Required External Fluxer Solvent Purge Required External Fluxer Solvent Purge Required		
External Fluxer Flux Volume out of Tolerance Warning 20 10 External Fluxer Restricted Flow Detected Warning 2 External Fluxer Servo Controller COMM Fault Warning 2 External Fluxer Solvent Level Low Ignore 2 External Fluxer Solvent Purge Required Warning 2	%	
External Fluxer Restricted Flow Detected External Fluxer Servo Controller COMM Fault External Fluxer Solvent Level Low External Fluxer Solvent Purge Required Warning		
External Fluxer Servo Controller COMM Fault Warning External Fluxer Solvent Level Low Ignore External Fluxer Solvent Purge Required Warning	%	
External Fluxer Solvent Level Low Ignore External Fluxer Solvent Purge Required Warning		
External Fluxer Solvent Purge Required Warning		
External Fluxer not On!!! Warning Warning		
		-
Repeat Time 1 minutes Current Value Range		

ITW EAE is a division of Illinois Tool Works, Inc. It is a consolidation of all of its Electronic Assembly Equipment and Thermal Processing Technology. The group includes world-class products from MPM, Camalot, Electrovert, Vitronics Soltec and Despatch.

Electrovert